



# TIME TO LIBERATE THE TEAM!

The Firefront™ Universal Appliance Communications System allows up seven X10DR Elite devices to be connected to the Fire appliance host mobile radio to provide a comprehensive, local intercom and network access system for fire fighters. Typical systems provide local atscene, off-network private AES secure communications with the ability to also monitor and transmit over the vehicle's main despatch mobile radio for up to 700 meters from the vehicle. Additional facilities include the ability to monitor other radio channels (e.g. volunteers using UHF radios) or the ability for multiple vehicles to link together into larger work teams with a shared local intercom network.

#### Intuitive

Built for intuitive operation, Firefront™ communication systems provides all team members with simple to use, lightweight, IP67 rated waterproof shoulder personal communicators, while ensuring effective, controlled access to the vehicle's main radio network, as well as seamless, local "off net" intercom capability including game changing Handsfree operation.

### Coverage

All communications between the X10DR Elite handsets occurs via their specific paired gateway units and not directly between handsets, so depending on location, communication between handsets could be over 1000 meters while communication back to the gateway device in the vehicle could be up to 700 meters. Effective maximum range of the system is significantly dependant on the location of the XRTG gateway installation and the location where the X10DR handset is actually worn by the user. Obstruction to antennas will effect the directivity of coverage so utmost care must be taken when selecting a mounting location when maximum range is a system imperative.

#### Handsfree and Press To Talk Local Intercom

All team members usually communicate with each other locally by pressing the top mounted Talkaround button on the Elite Microphone. For those situations where both hands are needed such as attaching a hose, the system also provides Handsfree full duplex mode. Handsfree mode is simply enabled by "double pressing" the Talkaround button. The user will hear a "handsfree" activation tone and a periodic reminder tone. The user can then communicate freely with others from their team while focusing on the task at hand without the need to press any buttons. Typically a user in Handsfree mode should wear a lightweight headset or perhaps a specific breathing apparatus headset plugged into the bottom Hirose® 6 pin headset port. Handsfree is simply disabled by pressing the Talkaround button again. If an authorized user is in handsfree mode and they need to communicate over a radio channel they simply press radio PTT.

# PTT Button toggle

To provide the optimum user interface, the large side PTT button can be **user assigned** between Radio PTT and Talkaround PTT. Doing so means the user always has a large PTT button no matter who they wish to talk to. In the radio position, the handset LED lights blue to indicate your transmissions are being sent over the air to the radio network. In The Local Talkaround position the LED lights Green to indicate your are communicating locally on ground. Naturally regardless, all local transmissions are heard as well as all authorized radio network transmissions.





### **Console Command Panel**

The Console Command Panel is normally located inside the vehicle cabin so user access can be pre-defined before arriving at the response scene. For long deployments where access requirements may evolve as circumstances change, an additional Console Command Panels can be mounted elsewhere on the vehicle for easy access and so as to prevent the need to climb back into the cabin when an urgent change is required.

#### Selective Radio Access

Besides the local intercom capabilities, the X10DR Firefront™ system also allows team members partial or full access to the vehicle's main or secondary mobile radio operating channels. On power up the system's normally configured to typically allow full radio system access to the vehicle's Commander, and/or a 2IC if so desired. Depending on the specific operational needs and equipment configuration, either one or both selectable user sub-groups (2 or 3 members) can be authorized access to the vehicle's radio/s by the Commander with a press of a button on the XCCP Console Command Panel. When a team member has radio monitor access assigned, they will hear both local intercom voice traffic as well as the assigned radio's receive audio. Should someone be talking in local intercom mode when a radio reception occurs on the assigned mobile radio, then audio from both sources will be mixed and users will hear both conversations. When authorized they can also transmit over the assigned radio channel by simply pressing the large side PTT button to talk.

## Super Groups

To further expand the local intercom network, the Firefront™ communications system can be "super-grouped" by use of 2nd attached mobile radio which could then allow multiple Firefront™ vehicle systems within range of each other who are sharing a common dedicated channel to be merged into a super-group where all Talkaround press to talk conversations are shared. Assignment of the super-group capability to team members is via the Console Command Panel in the same manner that main radio access is granted. If enabled, the Commander would again normally have automatic access to the super-group channel.

Note: Handsfree mode cannot be operational when super-grouping is enabled.

## Volunteer connectivity

The vehicle's Firefront<sup>™</sup> system to be cross connected to a LMR/FRS/CB/PMR channel via the second connected radio and assigned by the vehicle Commander so those on-site team conversations can be shared with volunteer fire fighters who may be operating on their own volunteer radio equipment. This configuration can also be used to achieve multiple Firefront system patching as described above by utilizing a volunteer radio channel.

## Talk Back Microphone - In Cabin Option

The XTBM Talk back Microphone keeps those who stay in the vehicle fully informed of what is being said over the radio or locally on ground. This ruggedized IP67 weatherproof speaker microphone delivers over 1W RMS of loud and clear audio power allowing the user to communicate with Intercom crew or other members over the radio.

# **TIME TO GET LIBERATED!**

- HANDSFREE DUPLEX TEAM TALKAROUND
- RELAY MODE RANGE EXTENSION
- AES 128 BIT ENCRYPTED VOICE
- WIRELESS FINGER PTT OPTION
- DRAMATIC NOISE REDUCTION
- VERY LOUD & CLEAR AUDIO
- SIMPLE INTUITIVE DESIGN
- TALKAROUND CAPABILITY
- MINIMAL USER TRAINING
- LIGHTWEIGHT & RUGGED
- SEAMLESS INTEGRATION
- DUAL RADIO CAPABILITY
- IP67 WATERPROOF MIC
- PATENTED INNOVATION
- ALL DAY OPERATION
- COST EFFECTIVE
- RELIABLE
- PROVEN



**XCCP Console Command Panel** 





WPATH-X10 Handsfree Headset (use with/without XIPB)

**XIPB** In-line PTT Button (use with headset)

XWPB Wireless PTT Button Provides:

- Mimics side button assignment
- For finger use "Handsfree" PTT
- Velcro attachment strap







**XFSB** Firefront Smart Box

**XMVC** mobile charger

X5MK-B 5 way mounting kit with battery back up

### Open Channel Group Communications

**XRTG Plus** 

Elite Plus Rooftop Gateway

Open channel group communications nurtures valuable team spirit - a work ethos that comes from entrusting one's organization's wireless communications to an "open channel" two way radio system. Fire Departments use two way because it's the only sure way to deliver instant shared group situation awareness for all members assigned to a specific operational channel.. that's unless the firefighter leaves the vehicle. The X10DR Out Of Vehicle Solution enables your entire team of responders constantly stay informed whether in or out of their vehicle. X10DR core capability ensure all members continue to hear all conversations instantly, so all your firefighters know what is going on, no matter whether they are heading down a highway to a fire or out of the Fire appliance responding to an incident.

## Staying Secure In Remote Work Environments

The vehicle mounted mobile radio is often the first responders' chief communication link to central command and other radio units. However, when an officer needs to go back and wait at the vehicle, to provide or receive an update, operations slow or at worst, come to a stand still, losing critical response time and placing lives at risk. X10DR is revolutionary technology, which allows officers to stay in constant communication with each other locally on-site or back to base, via their vehicle mounted mobile radio, for up to five hundreds meters (over a quarter of a mile) from the vehicle.

## Command/Automatic Relay Mode

The X10DR Elite Plus now feature the unique ability for a handset user to activate Relay mode whereby a partner's handset that has lost direct connection with the vehicle gateway will then have their communications seamlessly relayed via their partner's Relay activated handset. Designed for in-to-building range enhancement, it would be typically deployed when entering buildings whose physical construction prevents an X10DR handset communicating back to their vehicle. The Relay handset user would remain in a location that remains connected to the vehicle while their partners enters deeper into the building to perform their duties. Naturally a third "Relay activated" handset can be left at that location allowing both officers to move around the building. As an added bonus should the Relay activated handset lose connection with the vehicle, it can continue to communicate with handsets linked to it. (See the X10DR Plus Plus user manual for a full description of capabilities.)



250 yards





**Relay Mode** via your partner's handset






# **6 Handset Application**

# Commander with 2 & 3 crew subgroups

Commander's handset can always transmit & receive on either enabled radios Commander decides which sub-groups can receive and/or transmit on whichever radios **XCCP** Console Command Panel




# **5 Handset Application**

Mounting Clip

# Commander with 2IC & one 3 crew subgroup

Commander & 2IC handsets can always transmit & receive on either enabled radios Commander decides if sub-group can receive and/or transmit on whichever enabled radios **XCCP** Console Command Panel



Now get totally liberated!



**X10DR Elite Plus** Rooftop Gateway

**XFSB-EXT** Firefront™ Smart Box External mount



**XCFC Custom Front** Cover option



**XCBC Custom Back** Cover option



**XLMC** Standard long rotary shoulder mount clip



**XVMC Velcro®** shoulder mount option includes Velcro patch - for best shoulder placement



**XWMC** Velcro® wireless charging mount option includes Velcro patch for best shoulder

placement



XMPA-ANT-U 1/4 wave helically

wound monopole whip antenna

- included







XMDM2 Mobile charger mounting arm



X1WK Mobile wireless charger



XRTR-U1 Patch Radio (CB)





**XCCP** Console Command Panel



Large In-Line PTT -for Peltor J11 Headset

#### WPWLP-X10D

Large In-Line PTT -for Draeger or similar **Breathing Apparatus** 



Velcro Clip Adaptor




For reference only Purchase elsewhere



X6WC 6 Way Desktop Charger

- includes AC/12VDC power supply.





**XTBM** 

**XDIA** 

Talk Back Remote Spk Mic



**Dual Adaptor** 



XIC-0.5 50cm interface



Mounting Clip



X10DR XWPB Wireless PTT **Button** 



**XMVC** Mobile charger



**XIPB** In-line PTT suits all X10DR audio accessories



WPHFH-X10 Headset Industrial lightweight



**Acoustic Tube** Headset Industrial lightweight

Works with:







NXDN"



more information at.

www.x10dr.com





Convright © 2020 Wireless Corporation Ltd. All rights reserved. WIRELESS PACIFIC, X10DR®, LIBERATE YOUR MOBILE RADIO, WHEN IT MATTERS are trademarks or registered trademarks of Wireless Corporation. All other trademarks are the property of their respective owners. V: 2020-O